






High Performance Treadmill Set Up
HS Elite and HS Pro




Front of treadmill

4.00in (10.16cm)
Minimum Distance from wall


72.00in (182.88cm)
Minimum Distance from back wall
or any obstacle




3




Bolt the back trap bracket to the base board.




4



Roll the treadmill forward and place the back feet into the trap bracket.




5



With the arch bolted together and on its side upright the arch.

6




Unbolt and removed bottom crossmember.

4


Roll the arch into position over the treadmill.

7




8

Plug in the powercord.
Turn the key to turn on
the treadmill.



Press the power button.
Then the start button.
Once the belt starts
moving, raise the incline
by pressing the incline up
button till max incline is
displayed (20 - 40%)
depending on model.


Turn the key to turn off
the treadmill and **remove
the powercord from the wall.**



Safety Note:

Always turn the key switch off and then remove the key and put it in a secure place to keep people without trained supervision off the treadmill.


9



Bring the safety channel through the bottom crossmember and bolt down to the base board and rear bracket.

Roll back the arch and bolt the crossmember back into place.

10



Plug the treadmill back in to the power outlet and turn on the treadmill.
By turning on the treadmill, it will return the incline back to its resting position

The treadmill is now ready for use.

